

# UMPQUA Research Company

Analytical Services  
ORELAP ID #OR100031

626 NE Division St - PO Box 609  
Myrtle Creek, OR 97457  
541-863-5201

## FILLING & SHIPPING INSTRUCTIONS FOR

### Gross Alpha/Beta, Radium, Uranium

The lab CAN NOT accept samples that are collected or shipped improperly or if the specified temperature is not maintained during shipping. Failure to meet these requirements will result in re-sampling. The filling information provided here is basic, and it is important to follow approved sampling procedures as described in the method. PLEASE, call the lab at the above phone number if you do not have access to method based sampling instruction or if you have any other questions.

#### **SAMPLE BOTTLES:**

Gross Alpha/Beta: 250 mL plastic

Uranium: 250 mL plastic

Radium: 1 gallon plastic

#### **SAMPLING INSTRUCTIONS:**

- 1) Rinse the bottle several times with water from the sample source.
- 2) Fill the sample bottle to just below the neck.
- 3) Replace the sample lid securely.

#### **SHIPPING INSTRUCTIONS:**

- 7) Return samples to the laboratory, no ice needed.