

**FILLING AND SHIPPING INSTRUCTIONS FOR
ASBESTOS**

PLEASE read the following instructions prior to sampling. If you have any questions, you may contact the lab at the above number.

NOTES:

- Always follow general principles for water sampling.
 - Fill 1 liter plastic container to the indicated fill line.
- 1) When sampling from a water tap, remove all hoses or fittings. Collect samples from a non-aerated faucet.
 - Allow the system to flush for approximately 5 minutes.
 - Rinse each container several times with source water prior to sample collection.
 - 2) When sampling from an open water source, **omit rinsing**. Submerge sample bottle; fill container to the fill line.
 - 3) Fill out container labels as required and store samples on ice.
 - 4) Complete the Chain of Custody, sign and date the **Subcontracting Form** as required, place documents in the watertight zip lock bag.
 - 5) **OVERNIGHT SHIP THE SAMPLES TO THE LAB IMMEDIATELY. ASBESTOS ANALYSES MUST BE PROCESSED WITHIN 48 HOURS.**

Ship samples to:

Eurofins Eaton Analytical Inc.
750 Royal Oaks Drive
Suite 100
Monrovia, CA 91016